

Wheel Chock Mounting Instructions:

1. Position the mower or ATV on the trailer bed in the exact location required.
2. Place the wheel chocks on the front and back of the rear tires.
3. Mark locations.
4. Secure the wheel chocks to the trailer bed with the right size nuts and bolts (not included). Ensure the bolts are 1" longer than the thickness of the trailer bed and chocks.
5. Use flat and spring washers. Self-locking nuts are also required.

Strap Installation:

1. Choose front or back E-slots, depending on the tire size.
2. Position the straps on the center of the tire.
3. Squeeze the e-fitting latch, and lock in the e-fitting to the desired slots in the wheel chock.