

## **Nozzle Installation Tips and Operation:**

### **Nozzle Height Adjustment:**

Nozzles can be used at various heights within the recommended range. However, this will affect the spray pattern width and the gallons per acre (GPA) applied.

### **Multi-Pass Spraying:**

When multi-pass spraying, be sure to overlap the ends of spray patterns 12-16 inches to ensure even coverage.

### **Adverse Wind Conditions:**

With boomless spray nozzles, as with other spraying methods, high or gusty wind conditions can cause drifting or pattern movements, adversely affecting spray coverage. If this occurs, wait for more favorable conditions before continuing.

### **Plumbing Requirements:**

Make sure that all plumbing and feed lines can properly supply the nozzle or nozzles at their rated GPM and PSI.

### **Spraying Safety:**

**Always wear protective clothing when spraying and/or handling any and all chemicals.**