

MOUNTING INSTRUCTIONS

G-O2™ Framed Mural Wall

The following is a guide to mounting the Garden Planter on your wall. The product is designed to be hung using standard dry wall. The design is compatible with anchors that look like the photographs to right .



Step #1: Scribe Line

Scribe a line at least 16 inches long that is approximately 2.25 inches lower than where you want the top of the panel. Mark the center location for the panel on this line, then a vertical mark 7.5 inches to the right of center and another 7.5 inches to the left of center. These two marks are the locations of the mounting holes.

The recommended anchors work in drywall, on a part of the wall without a stud behind the drywall. You will not need to use the anchors if you hit a stud; simply use the screw provided and go directly into the stud.

Step #2: Insert Anchors

Using a screwdriver, insert the anchor into the wall at the marks made in Step #1. Insert the anchor screws into the anchor until about ½ of an inch of the screw remains exposed. This makes it easier to hang the planted panel.

Step #3: Hang Planter Base

Hanging the planter will sometimes cause small amounts of soil to be dislodged during the process, so a drop cloth is suggested to protect your floor.

The heads of the anchors will fit through the larger of the two key slot holes on back (Figure 2).

Hang Planter from these screws and tighten them until the screw head contacts the Planter. (Figure 3)



Figure 2



Figure 3

Step #4: Assemble Frame

Remove the Drip Pan and cover from the Frame and set them aside. On the back of the Frame there are two (2) tabs along the top. These tabs hang off the top of the Planter Base. These tabs will line up properly when the inside of the Frame is aligned with the perimeter of the Base. (Figure 4)



Using caution to move any plants out of the way, position the Frame over the base with the Frame opening about $\frac{3}{4}$ of an inch higher than the Base perimeter. This provides adequate clearance for engaging the slots. Slide the Frame down adjusting as necessary to enable slots on the frame onto the panel Base.



Step #5: Assemble Drip Pan & Catch Basin



Slide the Drip Pan into the opening between the Frame and the Base on the top of the unit.

Once the Drip Pan is seated properly, the cover sits on top of the Drip Pan and virtually disappears from view when seated properly.



A petcock on the bottom of the unit can be opened and closed for draining excess water from the catch basin.

You can now relax and enjoy your Garden Art!