

Installation Instructions for the Cargo Door Lever Lock

Before installing the Cargo Door Lever Lock be sure the trailer is secured (tires chalked, brakes applied) and will not move.

- 1. Install the Cargo Door Lever Lock by first removing the retaining pin and aligning the lock with the trailer handle as shown. (Figure 1)**
- 2. Check the alignment of the keeper holes (where a padlock would normally be inserted) to see that they are aligned and there is a clear path for the retaining pin to be inserted. (Figure 2)**
- 3. Install the Cargo Door Lever Lock over the handle and keepers as shown. (Figure 3)**
- 4. Insert the retaining pin as shown. (Figure 4) Some alignment may be needed by depressing the handle inward so the retaining pin can slide freely.**
- 5. With the keys removed, depress the locking button and store keys in a secure location.**

Install additional Equipment Lock devices to secure your trailer.

Removal of the Cargo Door Lever Lock

- 1. Insert key, turn clockwise and lock button will pop out.**
- 2. While holding the Cargo Door Lever Lock in position, lift the retaining pin completely out off the Cargo Door Lever Lock body.**

Some alignment may be needed by depressing the handle inward so the retaining pin can slide freely.

- 3. Remove the Cargo Door Lever Lock from your trailer, re-insert the retaining pin and lock it into place.**
- 4. Store the Cargo Door Lever Lock and keys in a secure location.**