

Instructions for using the DIGITAL ACCU-GAGE

The electronic digital gage is simple to operate and read. Turn on and off using the “on/off” button. It is best to turn off when not in use to prolong the life of the battery. You can switch from Imperial to Metric mode using the “mm/inch” button. If the gage reads any number other than .000 inch or .00 mm when the gage is at rest, touch the “zero” button and hold it until the numbers go back to zero.

Maintenance

Always treat the ACCU-GAGE as a precision instrument that requires gentle handling and care. Avoid using on mowers that are wet to minimize any water getting inside the gage. Keep clean using a soft cloth and cleaning solution such as naphtha (lighter fluid). Change or clean the battery whenever the display is blinking or the numbers do not show correctly. A new battery should last about a year. Be careful to put the battery back in the same way as it was removed. The battery case is located on the left side of the gage when looking at the face.

Troubleshooting

Almost all troubles with an electronic digital gage are battery related. First, remove the battery and clean it with a soft cloth moistened with some WD 40. Then re-insert it. If the gage still does not work properly, insert a new battery after cleaning it per above instructions.

Make sure the new battery is fresh and avoid touching with your fingers. Use a cloth to hold it and place it in the battery holder.

